NEW ZIG ZAG

GEIGER

	DIP SWITCH					
	1	2	3	4	5	6
1coin 1play	off	off				
2coins 1play	on	off				
1coin 2plays	off	on				
free play	on	on	off			
3 persons			off			
4 persons			on			
table				off		
upright				on		
Bonus 10,000					off	off
Bonus 20,000					on	off
Bonus 30,000					off	on
Bonus 40,000					on	on

Parts Surface A		Solder Surface B
2P Shoot	1	SYNC
2P Left	2	Green
2P Right	3	Blue
Red	4	1P Left
1P Shoot	5	1P Right
Coin SW	6	1P Start
	7	2P Start
2P Up	8	1P Up
2P Down	9	1P Down
+5V	10	+5V
	11	
	12	
	13	
+12V	14	+12V
Speaker	15	
GND	16	GND
GND	17	GND
GND	18	GND