

Lötseite

GND 1
 + 5 Volt 2
 + 12 Volt 3
 LSP 4
 1. Pl. Schuss 5
 1. Pl. Down 6
 1. Pl. Rechts 7
 2. Pl. Schuss 8
 2. Pl. Down 9
 2. Pl. Rechts 10
 2. Pl. Start 11
 1. Pl. Start 12
 Coin 1 13
 14
 15
 16
 17
 18
 Sync. 19
 Grün 20
 + 5 Volt 21
 GND 22

Bestückungsseite

GND
 + 5 Volt
 + 12 Volt
 LSP
 Lautsprecher
 1. Pl. Up
 1. Pl. Links
 GND
 2. Pl. Up
 2. Pl. Links
 GND
 GND
 GND
 GND
 1. Pl. Turn
 2. Pl. Turn
 GND
 Rot
 Blau
 + 5 Volt
 GND

DIP SW A

Number of Player
 5
 2
 1
 3
 Bonus Point
 1st 30,000/2nd 100,000
 after 100,000
 1st 30,000/2nd 80,000
 after 80,000
 1st 20,000/2nd 100,000
 after 100,000
 1st 20,000/2nd 80,000
 after 80,000
 Upright
 Table
 COIN 1
 Free Play
 1credit 4coin
 1credit 3coin
 3credit 2coin
 1credit 2coin
 4credit 1coin
 2credit 1coin
 1credit 1coin

	1	2	3	4	5	6	7	8
5	ON	ON						
2	ON	OFF						
1	OFF	ON						
3	OFF	OFF						
Bonus Point								
1st 30,000/2nd 100,000				ON	ON			
after 100,000								
1st 30,000/2nd 80,000				ON	OFF			
after 80,000								
1st 20,000/2nd 100,000				OFF	ON			
after 100,000								
1st 20,000/2nd 80,000				OFF	OFF			
after 80,000								
Upright						ON		
Table						OFF		
COIN 1								
Free Play						ON	ON	ON
1credit 4coin						ON	ON	OFF
1credit 3coin						ON	OFF	ON
3credit 2coin						ON	OFF	OFF
1credit 2coin						OFF	ON	ON
4credit 1coin						OFF	ON	OFF
2credit 1coin						OFF	OFF	ON
1credit 1coin						OFF	OFF	OFF

DIP SW B

Screen Stop
 Normal
 Difficulty Very Difficult
 " Difficult
 " Easy
 " Very Easy

	1	2	3	4	5	6	7	8
Screen Stop	ON	OFF						
Normal	OFF							
Difficulty Very Difficult	ON	ON						
" Difficult	ON	OFF						
" Easy	OFF	ON						
" Very Easy	OFF	OFF						

COIN 2 (Same to COIN 1)

Screen Reverse
 Normal
 Test Mode
 Normal

	1	2	3	4	5	6	7	8
Screen Reverse				ON				
Normal				OFF				
Test Mode						ON		
Normal						OFF		