

1942

SOLDER SIDE	NO	COMPONENT SIDE
GND	1	GND
+5	2	+5
+12	3	+12
<del>SPEAKER</del>	4	<del>SPEAKER</del>
Speaker	5	Speaker
IP. FIRE	6	IP. UP
IP. DOWN	7	IP. LEFT
IP. RIGHT	8	
RP. FIRE	9	RP. UP
RP. DOWN	10	RP. LEFT
RP. RIGHT	11	GND
RP. START	12	GND
IP. START	13	GND
COIN	14	GND
	15	GND
	16	IP. RETURN
	17	RP. RETURN
	18	
SYNC	19	RED
GREEN	20	BLUE
+5V	21	+5V
GND	22	GND

1942