

# AIR BUSTER

<u>SOLDERSIDE</u>		<u>PARTS SIDE</u>										
GND	1	GND		DIP SW A	1	2	3	4	5	6	7	8
GND	2	GND		SCREEN REVERSE	OFF	ON						
+5V	3	+5V		NORMAL		OFF						
+5V	4	+5V		TEST MODE			ON					
	5			NORMAL			OFF					
+12V	6	+12V						OFF				
	7			COIN A								
COIN COUNTER 2	8	COIN COUNTER 1		1coin 1play					OFF	OFF		
COIN LOCKOUT 2	9	COIN LOCKOUT 1		1coin 2play					ON	OFF		
SPEAKER(-)	10	SPEAKER(+)		2coin 1play					OFF	ON		
AUDIO(GND)	11	AUDIO(+)		2coin 3play					ON	ON		
VIDEO GREEN	12	VIDEO RED		COIN B								
VIDEO SYNC	13	VIDEO BLUE		1coin 1play							OFF	OFF
SERVICE SW	14	VIDEO GND		1coin 2play							ON	OFF
TILT SW	15	TEST SW		2coin 1play							OFF	ON
COIN SW 2	16	COIN SW 1		2coin 3play							ON	ON
START SW 2	17	START SW 1										
2P UP	18	1P UP		DIP SW b	1	2	3	4	5	6	7	8
2P DOWN	19	1P DOWN		DIFFICULT								
2P LEFT	20	1P LEFT		NORMAL	OFF	OFF						
2P RIGHT	21	1P RIGHT		EASY	ON	OFF						
2P PUSH 1	22	1P PUSH 1		DIFFICULT	OFF	ON						
	23			HARD	ON	ON						
	24						OFF					
	25			SCREEN STOP				OFF				
	26			NORMAL				ON				
GND	27	GND		NUMBER OF PLAYER								
GND	28	GND		3					OFF	OFF		
				4					ON	OFF		
				5					OFF	ON		
				7					ON	ON		
				DEMO SOUND							ON	
				NO DEMO SOUND							OFF	OFF