

# ARKANOID




## CONNECTION DIAGRAM

<u>PART SIDE</u>		<u>SOLDER SIDE</u>	
1	+ 12V	A	+ 12V
2	RED	B	
3	GREEN	C	BLUE
4	SYNC	D	
5		E	SPEAKER
6	+ 5V	F	+ 5V
7	+ 5V	H	+ 5V
8	COIN	J	
9		K	
10		L	
11		M	
12	1P START	N	2P START
13	GND	P	GND
14	GND	R	GND
15	1P SENSOR	S	2P SENSOR
16	1P SENSOR	T	2P SENSOR
17		U	
18		V	
19		W	
20		X	
21	<i>1P Shoot</i>	Y	
22	1P SHOOT	Z	2P SHOOT

*1 Knopf*



*Monitor*



*1 Dreh-Knopf*

\*\*\* THIS ARKANOID CAN SELECT THE STAGES YOU WANT TO PLAY\*\*\*\*\*

1. TURN THE POWER SW. ON.

2. TURN THE LEVER KNOB AND SELECT STAGE YOU WANT.