

TRANSFORMER (ASTRO FLASH)

GAME PRICE SETTINGS

DIP SW #1

OPTION	1	2	3	4	5	6	7	8
1 COIN 1 CREDIT	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1 COIN 2 CREDITS	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
1 COIN 3 CREDITS	OFF	ON	OFF	OFF	ON	OFF	OFF	OFF
1 COIN 4 CREDITS	ON	ON	OFF	OFF	ON	ON	OFF	OFF
1 COIN 5 CREDITS	OFF	OFF	ON	OFF	OFF	ON	OFF	OFF
1 COIN 8 CREDITS	ON	OFF	ON	OFF	ON	OFF	ON	OFF
2 COINS 1 CREDIT	OFF	ON	ON	OFF	OFF	ON	ON	OFF
3 COINS 1 CREDIT	ON	ON	ON	OFF	ON	ON	ON	OFF
4 COINS 1 CREDIT	OFF	OFF	OFF	ON	OFF	OFF	OFF	ON
2 COINS 3 CREDITS	ON	OFF	OFF	ON	ON	OFF	OFF	ON
2 COINS 1 CREDIT								
4 COINS 2 CREDITS								
5 COINS 3 CREDITS	OFF	ON	OFF	ON	OFF	ON	OFF	ON
6 COINS 4 CREDITS								
2 COINS 1 CREDIT	ON	ON	OFF	ON	ON	ON	OFF	ON
4 COINS 3 CREDITS								
1 COIN 1 CREDIT								
2 COINS 2 CREDITS								
3 COINS 3 CREDITS	OFF	OFF	ON	ON	OFF	OFF	ON	ON
4 COINS 4 CREDITS								
5 COINS 8 CREDITS								
1 COIN 1 CREDIT								
2 COINS 2 CREDITS	ON	OFF	ON	ON	ON	OFF	ON	ON
3 COINS 3 CREDITS								
4 COINS 5 CREDITS								
1 COIN 1 CREDIT	OFF	ON	ON	ON	OFF	ON	ON	ON
2 COINS 3 CREDITS								
1 COIN 1 CREDIT	ON	ON	ON	ON	ON	ON	ON	ON

COIN SW #1

COIN SW #2

GAME OPTION SETTING

DIP SW #2

OPTION	1	2	3	4	5	6	7	8
ADVERTISE OFF		OFF						
SOUND ON		ON						
NUMBER OF PLAYER 3			OFF	OFF				
4			ON	OFF				
5			OFF	ON				
FREE			ON	ON				
EXTRA PLAYER NORMAL					OFF	OFF		
EASY					ON	OFF		
HARD					OFF	ON		
HARDEST					ON	ON		
GAME DIFFICULTY NORMAL							OFF	OFF
EASY							ON	OFF
HARD							OFF	ON
HARDEST							ON	ON
1P ONLY	OFF							
1 or 2P	ON							

SOLDER SIDE

PARTS SIDE

	1	
COIN 2	2	COIN 1
SERVICE	3	TEST
	4	
2P START	5	1P START
DOWN	6	UP
LEFT	7	RIGHT
SHOOT 2	8	SHOOT 1
	9	
	10	
	11	
	12	
	13	
GREEN	14	RED
SYNC	15	BLUE
	16	
	17	
	18	GND
	19	COIN COUNTER
	20	
	21	
	22	
	23	+5V
	24	GND
+12V	25	+12V
	26	GND
	27	SPEAKER
	28	SPEAKER

+12V