

# BATGUN

TM


## HOW TO PLAY

DESTROY ALL ENEMYS BY USING 8-WAY JOYSTICK AND 2 PUSH BUTTONS (SHOT & BOMB). POWER UP AND BOMB ITEMS APPEAR BY DESTROYING ITEM CARRIERS.

V-ITEM (BONUS POINTS) APPEARS BY DESTROYING BUILDINGS, ENEMYS AND I'ITEM BOXES.

WEAPON POWER INCREASES MORE AND MORE BY DESTROYING ENEMY'S TOUGH LEVEL. WHEN YOU ARE ATTACKED AND HIT BY ENEMY, YOU WILL LOSE YOUR FIGHTER. WHEN YOU LOSE ALL FIGHTERS, GAME WILL BE OVER.

THE SECRET OF SUCCESS IS TO MAKE WEAPON POWER GROW UP AND TO USE BOMB TIMELY.



8WAY JOYSTICK



SHOT



BOMB

## JAMMA

SOLDER FACE		PARTS FACE	
GND	A 1	GND	
GND	B 2	GND	
+5V	C 3	+5V	
+5V	D 4	+5V	
N.C.	E 5	N.C.	
+12V	F 6	+12V	
	H 7		
COIN COUNTER 2	J 8	COIN COUNTER 1	
(COIN LOCK OUT 2)	K 9	(COIN LOCK OUT 1)	
SP (-)	L 10	SP (+)	
N.C.	M 11	N.C.	
VIDEO GREEN	N 12	VIDEO RED	
VIDEO SYNC	P 13	VIDEO BLUE	
SERVICE SW	R 14	VIDEO GND	
	S 15	TEST SW	
COIN SW 2	T 16	COIN SW 1	
START SW 2	U 17	START SW 1	
2P UP	V 18	1P UP	
2P DOWN	W 19	1P DOWN	
2P LEFT	X 20	1P LEFT	
2P RIGHT	Y 21	1P RIGHT	
2P PUSH 1	Z 22	1P PUSH 1	
2P PUSH 2	a 23	1P PUSH 2	
N.C.	b 24	N.C.	
N.C.	c 25	N.C.	
N.C.	d 26	N.C.	
GND	e 27	GND	
GND	f 28	GND	


**DIP SW 1**

\*FACTORY CHOICE

		1	2	3	4	5	6	7	8
GAME STYLE	* NORMAL CONTINUE DISCOUNT CONTINUE	OFF ON							
PICTURE INDICATE	* NORMAL REVERSE		OFF ON						
FUNCTION CHECK	* NORMAL PLAY TEST PATTERN			OFF ON					
DEMO SOUND	* ON NO SOUND				OFF ON				
COIN SW1	* 1coin / 1credit 1 2 2 1 2 3					OFF ON OFF ON	OFF ON ON ON		
COIN SW2	* 1coin / 1credit 1 2 2 1 2 3							OFF ON OFF ON	OFF ON ON ON

**DIP SW 2**

		1	2	3	4	5	6	7	8
DIFFICULTY	* B NORMAL A EASY C DIFFICULT D MORE DIFFICULT	OFF ON OFF ON	OFF OFF ON ON						
EXTRA PLAYER	* 1,000,000 ONLY 500,000/600,000 EACH 1,500,000 ONLY NO EXTRA PLAYER			OFF ON OFF ON	OFF OFF ON ON				
NUMBER OF PLAYER	* 3 5 2 1					OFF ON OFF ON	OFF OFF ON ON		
GAME MODE	* NORMAL MODE INVINCIBLE MODE							OFF ON	
CONTINUE PLAY	* ON OFF								OFF ON



**TOAPLAN Co., Ltd.**

TOA BLDG.  
1-8-4 SHIMIZU, SUGINAMI-KU TEL:03-5397-5111  
TOKYO, 167, JAPAN FAX:03-5397-4755