BREYWOOD "

200					
Wiring Diagram					
Solder side	25		<u>Component</u> S	<u>ide</u>	
GND	1		GND		
GND	2		GND		
+ 5V	1103 TTO		+5 V		
+5V	4 440		+5V		
	4305 NO.				
+12V	6		+12V		
	1107 T10				
COIN 2	8		COIN 1		
	9				
SPEAKER(-)	10		SPEAKER (+)	008 -	
	99011 930				
GREEN	12		RED		
SYNC	41013 NO		BLUE		
SERVICE SW	14 HO		GND		*
	99015 990				
COIN SW 2	HO16 TAO		COIN SW1		
START SW 2	99017 NO		START SW 1	7000	
2P UP	18		1P UP		
2P DOWN	19		1 P DOWN		
2P BEFT TO THE	20		1P LEFT		
2P RIGHT	21		1P RIGHT		
2P PUSH 1	22		1P PUSH 1		
2P PUSH 2	23		1P PUSH 2		
	24				
	25				
	26				
GND	27		GND		
GND	28		GND		
Dips witch 1		1 2	2: 43 5 4	7 58 6	7 8
SREEN NORMAL		OFF			
INVERSE		ON			
NOT USING		OF	F OFF OFF OFF	OFF OFF OFF	OFF
SCREEN STOP			9		
NO	i i				OFF
ÝES		3			ON

Component Side

DIPS WIT	ГСН 2	all a	2	3	2 4	5	6	7 6 6 8
POWER	1000	OFF	OFF	OFF	OFF			
	200	OFF	OFF	OFF	ON			
	300	OFF	OFF	ON	OFF			
		OFF	OFF	ON	ON			
	500	OFF	ON	OFF	OFF			
	600	OFF	ON	OFF	ON			COIN 2
	700	OFF	ON	ON	OFF			
	800	OFF	ON	ON	ON		2 m(=)	
	900	ON	OFF	OFF	OFF			
	2000	ON	OFF	OFF	ON			NEED OFFER
	3000	ON	OFF	ON	OFF			OMAS A
	4000	ON	OFF	ON	ON		WB.	
	5000	ON	ON	OFF	OFF			
	6000	ON	ON	OFF	ON			
	7000	I WE TON E	ON	ON	OFF			START S
	8000	ON	ON	ON	ON			
	GANE DIFFICU	JLTY WOOD 9 I						
	NORMAL					OFF	OFF	
	1					ON	OFF	
	2					OFF	ON	
	3					ON	ON	
	NOT USING							OFF
	DEMO SOUND							0
	NO							OFF
	YES							ON

OFF OFF OFF OFF OFF OFF OFF

0