



# BRICK ZONE

## 1. CONTROL PANEL

### 2 PLAYER INTERACTIVE



CONTROLLER OF BAT




SHOT BUTTON




EMERGENCY BUTTON

## 2. HOW TO CONTROL



A CASE THE BALL HIT CENTER OF BAT



A CASE THE BALL HIT SIDE OF BAT

## 3. POINT TABLE

BREAK A BRICK	100
CATCH A ITEM	200-300
COMBINE A WORD	2000-7000
HIT THE BOSS	100-300
KILL THE BOSS	3000
CLEAR UP STAGE	3000

## 4. KINDS OF ITEMS

### CHANGE THE FUNCTION OF BAT

	NORMAL BAT		FIRE BULLET
	A MAGNET BAT		INCREASE IN NUMBER OF BALL x2
	FIRE A MISSILE		FIRE BULLET OF 3 WAY
	LENGTHEN THE BATS SIZE		DECREASE THE BATS SIZE

### CHANGE THE FUNCTION OF BALL

	SUPER BALL		SPRIT INTO 3 BALL
	SPRIT INTO 5 BALL		FIRE OF MISSILE
	FIRE BULLET OF 4 WAY		FIRE BULLET OF ROTATION
	FIRE BULLET OF 3 WAY		

### THE OTHERS

	SLOW SPEED OF BALL		INCREASE IN NUMBER OF PROTECTION NET
--	--------------------	--	--------------------------------------

### COMBINE A WORD

	+4000 BONUS +4000
	-3000 BONUS -3000
	JUMP-2 OVER THE STAGE
	EXIT-1 ASSEMBLE THE PICTURES
	CLEAR FINISH STAGE OF THE PRESENT





