

COOKIE&BIBI2

DIP SW 1

SETTING	POSITION	1	2	3	4	5	6	7	8	
DEMO SOUND	* SOUND OFF SOUND ON	OFF ON								
2 PLAY MODE	* 3 SET 5 SET	OFF ON								
PLAY PRICING COIN	* 1COIN 1PLAY 1COIN 2PLAY 2COIN 3PLAY 2COIN 1PLAY 3COIN 1PLAY 4COIN 1PLAY 5COIN 1PLAY			OFF ON OFF OFF ON OFF ON	OFF OFF ON OFF ON ON ON	OFF OFF OFF ON ON ON ON				
GAME DIFFICULTY	* NORMAL HARD VERY HARD EASY						OFF ON OFF ON	OFF OFF ON ON		