

E X T E R M I N A T I O N

<u>Solder Side</u>		<u>Parts Side</u>		<u>DIP-SW A</u>								
				1	2	3	4	5	6	7	8	
GND	1	GND		SCREEN REVERSE	OFF	ON		OFF				
GND	2	GND		SCREEN NORMAL	OFF	OFF		OFF				
+5V	3	+5V		TEST MODE	OFF		ON	OFF				
+5V	4	+5V		NORMAL GAME	OFF		OFF	OFF				
	5			PLAY CHARGE (Coin A)								
	6	+12V (+13V)		1coin 1play	OFF		OFF	OFF	OFF			
+12V	7	POST		1coin 2play	OFF		OFF	ON	OFF			
POST	8	COIN COUNTER 1		2coin 1play	OFF		OFF	OFF	ON			
COIN COUNTER 2	9	COIN COUNTER 1		2coin 3play	OFF		OFF	ON	ON			
COIN LOCKOUT 2	10	COIN LOCKOUT 1		PLAY CHARGE (Coin B)								
SPEAKER OUT(-)	11	SPEAKER OUT(+)		1coin 1play	OFF		OFF			OFF	OFF	
	12			1coin 2play	OFF		OFF			ON	OFF	
VIDEO G	13	VIDEO R		2coin 1play	OFF		OFF			OFF	ON	
VIDEO SYNC	14	VIDEO B		2coin 3play	OFF		OFF			ON	ON	
SERVICE SW	15	VIDEO GND										
TILT SW	16	COIN A		<u>DIP-SW B</u>	1	2	3	4	5	6	7	8
(COIN B)	17	SELECT-1		DIFFICULTY								
SELECT-2	18	1P UP		Rank B	OFF	OFF	OFF	OFF	OFF	OFF		
2P UP	19	1P DOWN		Rank A	ON	OFF	OFF	OFF	OFF	OFF		
2P DOWN	20	1P LEFT		Rank C	OFF	ON	OFF	OFF	OFF	OFF		
2P LEFT	21	1P RIGHT		Rank D	ON	ON	OFF	OFF	OFF	OFF		
2P RIGHT	22	1P SHOT BUTTON		RATE OF LIFE DECREASE								
2P SHOT BUTTON	23	1P ESP BUTTON		1.0			OFF	OFF	OFF	OFF	OFF	OFF
2P ESP BUTTON	24			1.5			OFF	OFF	OFF	OFF	ON	OFF
	25			2.0			OFF	OFF	OFF	OFF	OFF	ON
	26			3.0			OFF	OFF	OFF	OFF	ON	ON
	27											
GND	28											
GND		GND										
		GND										

