

# DIP SW 1

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8	
DEMO SOUND	NO YES	OFF ON								
BONUS	NO BONUS * 10000 ONLY 30000 ONLY 50000 ONLY 50000. EVERY 50000 100000. EVERY 50000 100000. EVERY 100000 200000. EVERY 100000		OFF ON	OFF OFF	OFF OFF					
COIN	* 1 COIN 1 CREDIT 1 COIN 2 CREDIT 1 COIN 3 CREDIT 1 COIN 4 CREDIT 2 COIN 1 CREDIT 3 COIN 1 CREDIT 4 COIN 1 CREDIT 5 COIN 1 CREDIT						OFF ON	OFF ON	OFF ON	
TEST	* NOMAL NO DIE								OFF ON	

# DIP SW 2

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8	
SCREEN REVERSE	NOMAL REVERSE	OFF ON								
GAME STYLE	UPRIGHT TABLE		OFF ON							
PAIR PLAY (ONLY UPRIGHT)	* YES NO			OFF ON						
NUMBER OF PLAYERS	2 3 4 5				OFF ON	OFF ON				
DIFFICULTY	EASY 1 2 3 4 * NOMAL 5 6 7 DIFFICULT 8						OFF ON	OFF ON	OFF ON	OFF ON

## \*WIRING DIAGRAM

SOLDER SIDE		PARTS SIDE	
GND	1	GND	
GND	2	GND	
+5V	3	+5V	
+5V	4	+5V	
	5		
+12V	6	+12V	
	7		
	8	COIN COUNTER	
	9		
SPEAKER (-)	10	SPEAKER (+)	
	11		
VIDEO G	12	VIDEO R	
VIDEO SYNC	13	VIDEO B	
	14	VIDEO GND	
	15		
COIN 2	16	COIN 1	
2P START	17	1P START	
2P UP (NOT USE)	18	1P UP (NOT USE)	
2P DOWN (NOT USE)	19	1P DOWN (NOT USE)	
2P LEFT	20	1P LEFT	
2P RIGHT	21	1P RIGHT	
2P JUMP	22	1P JUMP	
2P SHOT	23	1P SHOT	
	24		
	25		
	26		
GND	27	GND	
GND	28	GND	