

IMMIGRANT

TM

CONNECTING DIAGRAM

SOLDERSIDE			PARTSIDE	
GND		A	1	GND
GND		B	2	GND
+5V		C	3	+5V
+5V		D	4	+5V
		E	5	
+12V		F	6	+12V
		H	7	
		J	8	
		K	9	
SPEAKER(-)		L	10	SPEAKER(+)
		M	11	
GREEN		N	12	RED
SYNC		P	13	BLUE
SERVICE SW		R	14	GND
		S	15	
COIN B		T	16	COIN A
2 P START		U	17	1 P START
2 P UP		V	18	1 P UP
2 P DOWN		W	19	1 P DOWN
2 P LEFT		X	20	1 P LEFT
2 P RIGHT		Y	21	1 P RIGHT
2 P ATTACK		Z	22	1 P ATTACK
2 P SPEED CHANGE		a	23	1 P SPEED CHANGE
		b	24	
		c	25	
		d	26	
GND		e	27	GND
GND		f	28	GND

