

TITLE: LASER STRIXX
NOTES:

LASER STRIXX is a "quix" game clone: the player has to close some areas thus slowly revealing a picture. In this case, the "hidden" digitised pictures have an erotic theme, and there is an unusual quantity of them, compared with the other same type games. Moreover, the STRIXX name has a precise meaning, being the fusion of QUIX and STRIP: for the most wanted bonus that the player can take is a strip-tease with moving video.

These are the main characteristics of the game:

- More than 250 pictures of wonderful girls, with 3 selectable hardness levels.
- High-quality digitised pictures.
- 6 different musical jingles.
- Bonus Strip: if the player can take it (it is the lips-shaped enemy) he can see, at the end of the level, a moving strip-tease.
- The player can choose amongst 5 strip-teasers: 4 females, 1 male.
- At every level-up, if the bonus was taken, the strip-teaser will take take off a garment, remaining at the end completely naked.
- 9 addictive levels with increasing difficulty.
- Complete credits management.
- Game continue.

The player has 5 different bonuses, that are taken when he closes one of the enemies into an area (Turbo, 1000 Points, Power Up, Stop, Strip Tease).

The energy decreases if:

1) One enemy collides while on the lines.

The energy decreases more when:

1) One enemy collides while outside the lines.

2) The monster collides.

The player loses its game when:

1) The energy level becomes too low.

2) The time finishes.

The player wins the level when he:

1) Covers more than 84% of the area.

2) "Closes" the monster while covering an area.



appartecchi e servizi per divertimento automatico

SISTEMA CUBO CD - JAMMA CONNECTIONS

JAMMA COMPONENT SIDE

1	1	GND
2	2	GND
3	3	+5 VOLT
4	4	+5 VOLT
5	5	-5 VOLT
6	6	+12 VOLT
7	7	KEY (nc)
8	8	N.C.
9	9	PUSH 6
10	10	SPEAKER +
11	11	STEREO SPEAKER +
12	12	VIDEO RED
13	13	VIDEO BLUE
14	14	VIDEO GND
15	15	PUSH 7
16	16	COIN 1
17	17	START 1
18	18	SU 1
19	19	GIU' 1
20	20	DES. 1
21	21	SIN. 1
22	22	PUSH1 - 1
23	23	PUSH2 - 1
24	24	PUSH3 - 1
25	25	PUSH4 - 1
26	26	PUSH5 1
27	27	GND
28	28	GND

JAMMA SOLDER SIDE

A 01	GND	A
B 02	GND	B
C 03	+5 VOLT	C
D 04	+5 VOLT	D
E 05	-5 VOLT	E
F 06	+12 VOLT	F
G 07	KEY (nc)	
J 08	N.C.	J
K 09	BONUS LINE	K
L 10	SPEAKER -	L
M 11	STEREO SPEAKER -	M
N 12	VIDEO GREEN	N
P 13	VIDEO SYNC	P
R 14	SERVICE SW	R
S 15	PUSH 7	S
T 16	COIN 2	T
U 17	START 2	U
V 18	SU 2	V
W 19	GIU' 2	W
X 20	DES.2	X
Y 21	SIN.2	Y
Z 22	PUSH1 2	Z
a 23	PUSH2 2	a
b 24	PUSH3 2	b
c 25	PUSH4 2	c
d 26	PUSH5 2	d
e 27	GND	e
f 28	GND	f