

II. Little Cabin DIP SWITCH MANUAL

DIP-SW1.

ITEM		1	2	3	4	5	6	7	8
COIN	1 COIN 1 CREDIT	OFF	OFF						
	2 COIN 2 CREDIT	ON	OFF						
	2 COIN 1 CREDIT	OFF	ON						
	3 COIN 1 CREDIT	ON	ON						
DEMO SOUND	YES					OFF			
	NO					ON			
SCREEN REVERSE	YES						ON		
	NO						OFF		
STRONGEST PLAYER	YES							ON	
	NO							OFF	
SCREEN TEST	YES								ON
	NO								OFF

DIP-SW2.

ITEM		1	2	3	4	5	6	7	8
DIFFICULT.	EASY	OFF	OFF						
	NORMAL	ON	OFF						
	HARD	OFF	ON						
	VERY HARD	ON	ON						
PLAYER LIFF	NO 2			OFF	OFF				
	NO 3			ON	OFF				
	NO 4			OFF	ON				
	NO 5			ON	ON				
PLAYER WINNER	When two players compets, winning twice is first.					OFF			
	When two player compets, winning three times is first					ON			
PLAYING TIME	180 (SEC)						OFF	OFF	
	150 (SEC)						ON	OFF	
	120 (SEC)						OFF	ON	
	90 (SEC)						ON	ON	