

# MAGIX

DIP SWICH.

		1	2	3	4	5	6	7	8
TEST MODE	YES NO	ON OFF							
DIFFIC- ULTY SET	NORMAL HARD HARDEST EASY		OFF ON OFF ON	OFF OFF ON ON					
SCREEN MODE	NORMAL REVERSE				OFF ON				
DEMO SOUND						ON OFF			
COIN/ CREDIT	1Coin1Cred it 1Coin2Cred it 1Coin3Cred it 1Coin4Cred it 2Coin1Cred it 2Coin3Cred it 3Coin1Cred it 4coin1Cred it						OFF ON OFF ON OFF ON OFF ON	OFF OFF ON ON OFF OFF ON ON	OFF OFF OFF OFF ON ON ON ON