

NINJA SPIRIT

SOLDIER SIDE

PARTS SIDE

GND	— 1	—	GND
GND	— 2	—	GND
+5V	— 3	—	+5V
+5V	— 4	—	+5V
	5		
+12V	— 6	—	+12V
	7		
COUNTER B	— 8	—	COUNTER A
GND (2)	— 9	—	GND (2)
SP (-)	— 10	—	SP (+)
	11		
GREEN	— 12	—	RED
SYNC	— 13	—	BLUE
SERVICE SW	— 14	—	GND
	15		
COIN B	— 16	—	COIN A
2P START	— 17	—	1P START
2P UP	— 18	—	1P UP
2P DOWN	— 19	—	1P DOWN
2P LEFT	— 20	—	1P LEFT
2P RIGHT	— 21	—	1P RIGHT
2P PUSH	— 22	—	1P PUSH
2P SHOOT	— 23	—	1P SHOOT
2P JUMP	— 24	—	1P JUMP
	25		
	26		
GND	— 27	—	GND
GND	— 28	—	GND

