


PANG

JAMMA規格 JAMMA STANDARD

半田面 SOLDER SIDE			部品面 PARTS SIDE
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
(not used) -5V	E	5	-5V (not used)
+12V	F	6	+12V
	H	7	
		8	COIN COUNTER 1
		9	COIN LOCK OUT 1
SP (-)	L	10	SP (+)
(not used)	M	11	(not used)
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
(not used)	S	15	(not used)
		16	COIN SW 1
START SW 2	U	17	START SW 1
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P PUSH1	Z	22	1P PUSH1
(not used)	a	23	(not used)
(not used)	b	24	(not used)
(not used)	c	25	(not used)
(not used)	d	26	(not used)
GND	e	27	GND
GND	f	28	GND

テストスイッチ・ボリュームの位置


Test Switch Volume Position



A: トータルボリューム
B: ボイス ボリューム

A: Total Volume Control
B: Voice Volume Control

○付属の遊び方シールの位置



イラストの筐体はこのゲームとは一切関係ありません。

○使用コネクター

CR7-56DA-3.06:(ヒロセ)

1168-056-009:(KEL)

MITCHELL CORP.

== P A N G ==

CHECK / CONDITION / DIP -> 1 2 3 4 5 6 7 8

**	1COIN/1CREDIT					ON	ON	ON
**	1COIN/2CREDITS					ON	ON	OFF
**	1COIN/3CREDITS					ON	OFF	ON
**	1COIN/4CREDITS					ON	OFF	OFF
**	2COIN/1CREDIT					OFF	ON	ON
**	3COIN/1CREDIT					OFF	ON	OFF
**	4COIN/1CREDIT					OFF	OFF	ON
**	5COIN/1CREDIT					OFF	OFF	OFF
**	PLAYERS - 1				ON	ON		
**	PLAYERS - 3				ON	OFF		
**	PLAYERS - 4				OFF	ON		
**	PLAYERS - 2				OFF	OFF		
**	EASY		ON	ON				
**	NORMAL		ON	OFF				
**	DIFICULT		OFF	ON				
**	VERY DIFICULT		OFF	OFF				
**	20,000							
**	100,000	OFF						
**	200,000							
**	1,000,000							
**	20,000							
**	50,000	ON						
**	100,000							
**	200,000							

P A N G
ON BOARD THE BOARD

ITEM	CONTENTS	1	2	3	4	5	6	7	8
DIFFICULTY	NORMAL	OFF	OFF						
	EASY	ON							
	HARD	OFF	ON						
	HARDEST	ON							
EXTEND									
NUMBER OF PLAYER	1				OFF	OFF			
	2				ON	ON			
	3				OFF	ON			
	4				ON	OFF			
COIN MODE	1COIN 1PLAY					OFF	OFF	OFF	
	1 2					OFF	OFF	ON	
	1 3					OFF	ON	OFF	
	1 4					OFF	ON	ON	
	2 1					ON	OFF	OFF	
	3 1					ON	OFF	ON	
	4 1					ON	ON	OFF	
	5 1					ON	ON	ON	

PANG. 배틀

		1	2	3	4	5	6	7	8
COIN	1 COIN 1 CREDIT						ON	ON	ON
	1 COIN 2 CREDIT						ON	ON	OFF
	1 COIN 3 CREDIT						ON	OFF	ON
	1 COIN 4 CREDIT						ON	OFF	OFF
	2 COIN 1 CREDIT						OFF	ON	ON
	3 COIN 1 CREDIT						OFF	ON	OFF
	4 COIN 1 CREDIT						OFF	OFF	ON
	5 COIN 1 CREDIT						OFF	OFF	OFF
PLAY	1 - PLAY				ON	ON			
	2 - PLAY				OFF	OFF			
	3 - PLAY				ON	OFF			
	4 - PLAY				OFF	ON			
DIFFICULTY	EASY		ON	ON					
	NOMAL		ON	OFF					
	Difficult		OFF	ON					
	VERY Difficult		OFF	OFF					
EXTRA PLAYER	1ST - 20,000 2ND - 50,000 3RD - 100,000 4TH - 200,000	ON							
	1ST - 20,000 2ND - 100,000 3RD - 200,000 4TH - 1,000,000	OFF							