

		SW	1	2	3	4	5	6	7	8
sound of Demonstration*	IMPOSSIBLE				OFF					
	Possible				ON					
vs system	* IMPOSSIBLE					OFF				
	Possible					ON				
difficulty	* easy		OFF				OFF			OFF
								OFF	OFF	
									ON	
	difficult								ON	ON

DIP SW 2

		SW	1	2	3	4	5	6	7	8
Game style	TABLE					OFF				
	UP RIGHT					ON				
Play charge coin 2	* 2 coin 1 PLAY						OFF	OFF		
	3 coin 1 PLAY							ON		
	4 coin 1 PLAY								OFF	
	5 coin 1 PLAY								ON	
Play charge coin 1	* 1 coin 1 PLAY								OFF	OFF
	1 coin 2 PLAY									ON
	1 coin 4 PLAY								OFF	OFF
	1 coin 5 PLAY								ON	ON

DIP SW 3

		SW	1	2	3	4	5	6	7	8
Play mode	* NORMAL		OFF							
	FREE PLAY		ON							
Round	* NORMAL			OFF						
	ROUND FREE			ON						
Back up	* NOT CLEAR				OFF	OFF		OFF		
	ALL CLEAR				ON					
TURN OVER PICTURE	* NORMAL						OFF			
	TURN OVER						ON			
set up mode	* GAME MODE									OFF
	TEST MODE									ON

P. SIDE		S. SIDE	
QND	A 1	QND	
QND	H 2	QND	
+5V	C 3	+5V	
(COIN COUNTER 2)	D 4	(LOCK OUT)	
+12V	E 5	+12V	
ROUND OUT (+)	F 6	ROUND OUT (-)	
VIDEO SYNC	H 7	(COIN COUNTER 1)	
VIDEO B	J 8	(COIN SW 2)	
VIDEO G	K 9	COIN SW 1	
VIDEO R	L 10	N-C	
1P DRIVE/SERVE	M 11	2P DRIVE/SERVE	
1P OUT/SERVE	N 12	2P OUT/SERVE	
1P BACK	P 13	2P BACK	
1P FORE	R 14	2P FORE	
1P RIGHT	S 15	2P RIGHT	
1P LEFT	T 16	2P LEFT	
N-C	U 17	N-C	
SELECT-1	V 18	SELECT-2	

CN-137



P I N G P O N G K I N G

<u>PARTS SIDE</u>		<u>SOLDERS SIDE</u>
GND	1	GND
GND	2	GND
+5V	3	+5V
(LOCK OUT)	4	(COIN COUNTER 2)
+12V	5	+12V
SOUND OUT (-)	6	SOUND OUT (+)
(COIN COUNTER 1)	7	VIDEO SYNC
(COIN SW 2)	8	VIDEO B
COIN SW 1	9	VIDEO G
N C	10	VIDEO R
2P DRIVE/SERVE	11	1P DRIVE/SERVE
2P CUT/SERVE	12	1P CUT/SERVE
2P BACK	13	1P BACK
2P FORE	14	1P FORE
2P RITGHT	15	1P RIGHT
2P LEFT	16	1P LEFT
N C	17	N C
SELECT-2	18	SELECT-1

DIP SW 1

	1	2	3	4	5	6	7	8
NO DEMO SOUND	OFF	OFF	OFF		OFF			
DEMO SOUND	OFF	OFF	ON		OFF			
NO FIGHTING SYSTEM	OFF	OFF		OFF	OFF			
FIGHTING SYSTEM	OFF	OFF		ON	OFF			
DIFFICULTY 1	OFF	OFF			OFF	OFF	OFF	OFF
2	OFF	OFF			OFF	OFF	ON	OFF
3	OFF	OFF			OFF	ON	OFF	OFF
4	OFF	OFF			OFF	ON	ON	OFF

DIP SW 2

	1	2	3	4	5	6	7	8
GAME STYLE TABLE	OFF	OFF	OFF	OFF				
UPRIGHT	OFF	OFF	OFF	ON				
PLAY CHARGE (COIN 2)								
2COIN 1PLAY	OFF	OFF	OFF		OFF	OFF		
3COIN 1PLAY	OFF	OFF	OFF		OFF	ON		
4COIN 1PLAY	OFF	OFF	OFF		ON	OFF		
5COIN 1PLAY	OFF	OFF	OFF		ON	ON		
PLAY CHARGE (COIN 1)								
1COIN 1PLAY	OFF	OFF	OFF				OFF	OFF
1COIN 2PLAY	OFF	OFF	OFF				OFF	ON
1COIN 4PLAY	OFF	OFF	OFF				ON	OFF
1COIN 5PLAY	OFF	OFF	OFF				ON	ON

DIP SW 3

	1	2	3	4	5	6	7	8
PLAY MODE								
NOMAL	OFF			OFF		OFF	OFF	
FREE	ON			OFF		OFF	OFF	
ROUND								
NOMAL		OFF		OFF		OFF	OFF	
FREE		ON		OFF		OFF	OFF	
HI-SCORE BACK UP								
NO CLEAR (AT RESET)			OFF	OFF		OFF	OFF	
CLEAR (AT RESET)			ON	OFF		OFF	OFF	
SCREEN NORMAL				OFF	OFF	OFF	OFF	
SCREEN REVERSE				OFF	ON	OFF	OFF	
GAME MODE				OFF		OFF	OFF	OFF
TEST MODE				OFF		OFF	OFF	ON