

# POKER BATS



OPTION DIP SW 1		S1	S2	S3	S4	S5	S6	S7	S8
C O I N 1	1 COIN 1 CREDIT	OFF	OFF	OFF					
	1 COIN 2 CREDIT	OFF	OFF	ON					
	1 COIN 3 CREDIT	OFF	ON	OFF					
	1 COIN 4 CREDIT	OFF	ON	ON					
	1 COIN 5 CREDIT	ON	OFF	OFF					
	1 COIN 6 CREDIT	ON	OFF	ON					
	2 COIN 3 CREDIT	ON	ON	OFF					
	3 COIN 4 CREDIT	ON	ON	ON					
	1 COIN 1 CREDIT				OFF	OFF	OFF		
	2 COIN 1 CREDIT				OFF	OFF	ON		
	3 COIN 1 CREDIT				OFF	ON	OFF		
	4 COIN 1 CREDIT				OFF	ON	ON		
	5 COIN 1 CREDIT				ON	OFF	OFF		
	6 COIN 1 CREDIT				ON	OFF	ON		
	3 COIN 2 CREDIT				ON	ON	OFF		
	4 COIN 3 CREDIT				ON	ON	ON		
CONTINUE	YES							OFF	
	NO							ON	
FREE PLAY	NO								OFF
	YES								ON

OPTION DIP SW 2		S1	S2	S3	S4	S5	S6	S7	S8
GAME DIFFICULTY	EASY	OFF	OFF						
	NORMAL	OFF	ON						
	HARD	ON	OFF						
	HARDEST	ON	ON						
LIVES	1 LIVE			OFF	OFF				
	2 LIVES			OFF	ON				
	3 LIVES			ON	OFF				
	4 LIVES			ON	ON				
LANGUAGE	ENGLISH					OFF			
	ITALIAN					ON			
WEAPON	YES						OFF		
	NO						ON		
NOT USED								X	
DEMO SOUND	YES								OFF
	NO								ON

P C B CONNECTOR JAMMA

SOLDER SIDE	PCB NO.	COMPONENTS SIDE
GND	A	GND
GND	B	GND
+5V	C	+5V
+5V	D	+5V
+12V	E	+12V
	F	
	G	
COIN COUNTER 2	H	COIN COUNTER 1
COIN LOCKOUT 2	J	COIN LOCKOUT 1
SPEAKER (-)	K	SPEAKER (+)
	L	
	M	
GREEN	N	RED
SYNC	P	BLUE
SERVICE	R	VIDEO GND
	S	
COIN IN 2	T	COIN IN 1
2P START	U	1P START
2P UP	V	1P UP
2P DOWN	W	1P DOWN
2P LEFT	X	1P LEFT
2P RIGHT	Y	1P RIGHT
2P PUSH L.	Z	1P PUSH L.
2P PUSH R.	a	1P PUSH R.
	b	
	c	
	d	
GND	e	GND
GND	f	GND

CONTROL PANEL

