



(A) PARTS FACE

SOLDER FACE (B)

- GND. 1
- GND. 2
- GND. 3
- +12V 4
- 12V 5
- ~~COIN METER~~ 6
- AUDIO OUT 7
- 8
- 9
- 1P START 10
- 2P START 11
- 1P UP-LEFT 12
- 1P DOWN-RIGHT 13
- 1P DOWN-LEFT 14
- 2P DOWN-RIGHT 15
- VIDEO RED 16
- VIDEO BLUE 17
- VIDEO GREEN 18
- 19
- GND 20
- GND 21
- GND 22



Q-BERT

PARTS SIDE		SOLDER SIDE	
GND	1		+5V
GND	2		+5V
GND	3		+5V
+12V	4		+12V
-12V	5		-12V
	6		
AUDIO OUT	7		
	8		
	9		SELECT SW.
1P START	10		COIN 1
2P START	11		COIN 2
1P UP -LEFT	12		2P DOWN -LEFT
1P DOWN -RIGHT	13		2P UP -RIGHT
1P DOWN -LEFT	14		2P UP -LEFT
2P DOWN -RIGHT	15		1P UP -RIGHT
TV RED	16		TV SYNC.
TV BLUE	17		
TV GREEN	18		
	19		
GND	20		+5V
GND	21		+5V
GND	22		+5V

SW.	1	2	3	4	5	6	7	8	
SOUND		-							NO SOUND
		0							SOUND
PLAY			-						FREE
			0						NORMAL
TYPE				-					UP RIGHT
				0					TABLE