

RISKY CHALLENGE

DIP SWITCHES

		SW 1							
		1	2	3	4	5	6	7	8
NUMBER OF PLAYERS	3	OFF	OFF						
	2	ON	OFF						
	4	OFF	ON						
	5	ON	ON						
DIFFICULTY	NORMAL			OFF	OFF				
	EASY			ON	OFF				
	HARD			OFF	ON				
SOUND IN ATTRACT MODE	NO							OFF	
	YES							ON	
DIAGNOSTIC TEST	NO								OFF
	YES								ON

		SW 2								
		1	2	3	4	5	6	7	8	
FLIP PICTURE	NO	OFF								
	YES	ON								
COIN CHUTE	SHARED			OFF	OFF					
	SEPARATE			ON						
MODE 1	1 COIN 1 GAME				OFF	OFF	OFF	OFF	OFF	
	2 COINS 1 GAME				OFF	ON	OFF	OFF	OFF	
	3 COINS 1 GAME				OFF	OFF	ON	OFF	OFF	
	4 COINS 1 GAME				OFF	ON	ON	OFF	OFF	
	5 COINS 1 GAME				OFF	OFF	OFF	ON	OFF	
	6 COINS 1 GAME				OFF	ON	OFF	ON	OFF	
	1 COIN 2 GAMES				OFF	OFF	ON	ON	OFF	
	1 COIN 3 GAMES				OFF	ON	ON	ON	OFF	
	1 COIN 4 GAMES				OFF	OFF	OFF	OFF	ON	
	1 COIN 5 GAMES				OFF	ON	OFF	OFF	ON	
	1 COIN 6 GAMES				OFF	OFF	ON	OFF	ON	
	2 COINS 3 GAMES				OFF	ON	ON	OFF	ON	
	3 COINS 2 GAMES				OFF	OFF	OFF	ON	ON	
	4 COINS 3 GAMES				OFF	ON	OFF	ON	ON	
	CONTINUE COIN				OFF	OFF	ON	ON	ON	
	FREE GAME				OFF	ON	ON	ON	ON	
	* A	1 COIN 1 GAME				ON	OFF	OFF		
		2 COINS 1 GAME				ON	ON	OFF		
		3 COINS 1 GAME				ON	OFF	ON		
		5 COINS 1 GAME				ON	ON	ON		
1 COIN 2 GAMES					ON			OFF	OFF	
** B	1 COIN 3 GAMES				ON			ON	OFF	
	1 COIN 5 GAMES				ON			OFF	ON	
	1 COIN 6 GAMES				ON			ON	ON	
	1-COIN 6 GAMES				ON			ON	ON	

* COIN CHUTE A

** COIN CHUTE B