


SEGA

TABLE TYPE


SPECIAL DUAL

PARTS CATALOG


SEGA OFFERS YOU THE UNBEATABLE COMBINATION OF QUALITY AND PLAY APPEAL IN AMUSEMENT GAMES



Item	Part No.	Description
1	AH-1036	Table Glass (560x860x5t)
2	CI-20001Y	Color Display Assy, 14H
3	CI-1026	Instruction Plate, Rear
4	DO-1033	TV Mask, Blue Smoke
5	96431-P-16	IC Board Assy, Special Dual
6	96431-P	IC Board Assy, Special Dual
7	S-94972	Noise Filter, AC 250V, 2A
8	90759X	Cable & Plug Assy
9	AH-1064	Instruction Plate, Front
10	AH-1010Y	Play Instructions Plate
11	S-93157	Volume Control, B-25KΩ
12	DO-1021	Color TV Mask, 14
13	96463X-P	Oscillator, Space Attack
14	BC-4603X	Power Amplifier, 5W
15	CC-2100	Coin Chute, Rejector Type, ¥100
16	96412-P	Oscillator, Head-On
17	AH-1046	Leg Arm
18	S-94156	Speaker, 12x8cm, 8Ω, 3W
19	S-90834	Switch, Push Button Type
20	AH-40003	Power Supply Assy (See Page 3 for Detail)
21	OL-3018	Extension Spring
22	S-96443	Switch, Rotary
23	AH-1032	Control Panel Assy (See Page 2 for Detail)
24	AH-1061	Coin Entry Plate
25	AH-1014	Knob
26	AH-1047	Leg
27	AH-1044	Leg Adjuster
	AH-0004	Leg Shoe
	S-96392	Push Button Switch, Yellow



Item	Part No.	Description
1	FL-1070	Push Button, Yellow
2	HO-1004	Control Unit
	HO-1006	Actuator
	HO-1007	Handle
	HO-1021	Shaft Holder
	S-91344	Switch, Micro Type
	S-82919	Handle Ball, 20φ, Black
3	AH-1045	Instruction Plate
4	TA-1039X	Control Unit
	TA-1036X	Handle Shaft
	TA-1038	Holder
	S-91421	Switch, Micro Type
	S-82971	Handle Ball, 20φ, Red
5	S-92028	Switch, Micro Type



Item	Part No.	Description
1	S-96262	AC Cord Connector Body
2	96559	Power Transformer, 9.5V, 12V, 14.5V x 2
3	S-96395	Switch Toggle, SP-DT, 15A
4	S-90645	Fuse, 1A
	S-90661	Fuse, 5A
5	S-96560	Switching Regulator, AC 100V, 5V, 6A
6	AH-4002	Regulator Unit
	S-95596	IC, μ A78M12UC
	S-96436	IC, μ A7812UC
	S-95866	IC, μ A7805UC