

# 戦球 取扱説明書

## OPERATOR'S MANUAL

SEN KYU (Battle Ball's)

### ◆仕様◆

SOLDER SIDE(半田面)	NO.	NO.	PARTS SIDE(部品面)
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
	E	5	
-12V	F	6	+12V
	H	7	
COIN COUNTER 2	J	8	COIN COUNTER 1
	K	9	
SPEAKER(-)	L	10	SPEAKER(+)
	M	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
	S	15	TEST SW
COIN IN 2	T	16	COIN IN 1
2P START	U	17	1P START
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P PUSH 1	Z	22	1P PUSH 1
2P PUSH 2	a	23	1P PUSH 2
	b	24	
	c	25	
	d	26	
GND	e	27	GND
GND	f	28	GND


○エッジコネクター  
EDGE CONNECTOR

○JAMMA規格 JAMMA STANDARD

○タテ画面 VERTICAL SCREEN

○コントロールパネル  
CONTRPL PANEL

8Way Joystick



PUSH 1  
左回転



PUSH 2  
右回転



○電源 POWER SOURCE +5V 5A  
+12V 1A

(電源は安定した電力を  
供給できるものをお使い下さい)

→ betätigen (gegen Name) dann Menu

CN1

1	SP + (左)
2	SP - (左)
3	SP + (右)
4	SP - (右)