

"STRAHL" DIP SW INSTRUCTION

DIP SW-1		1	2	3	4	5	6	7	8
COIN-1	1 Coin 1 Play	OFF	OFF	OFF					
	1 Coin 2 Play	ON	OFF	OFF					
	1 Coin 3 Play	OFF	ON	OFF					
	1 Coin 4 Play	ON	ON	OFF					
	2 Coin 1 Play	OFF	OFF	ON					
	3 Coin 1 Play	ON	OFF	ON					
	4 Coin 1 Play	OFF	ON	ON					
5 Coin 1 Play	ON	ON	ON						
COIN-2	1 Coin 1 Play				OFF	OFF	OFF		
	1 Coin 2 Play				ON	OFF	OFF		
	1 Coin 3 Play				OFF	ON	OFF		
	1 Coin 4 Play				ON	ON	OFF		
	2 Coin 1 Play				OFF	OFF	ON		
	3 Coin 1 Play				ON	OFF	ON		
	4 Coin 1 Play				OFF	ON	ON		
5 Coin 1 Play				ON	ON	ON			
SCREEN FLIP	Up Down							OFF ON	
DEMO SOUND	Off On								OFF ON

DIP SW-2		1	2	3	4	5	6	7	8
PLAYER	3	OFF	OFF						
	2	ON	OFF						
	4	OFF	ON						
	5	ON	ON						
GAME LEVEL	Normal			OFF	OFF				
	Easy			ON	OFF				
	Hard			OFF	ON				
	Hardest			ON	ON				
EXTEND	100000, 100000						OFF	OFF	
	50000, 100000						ON	OFF	
	100000, 200000						OFF	ON	
	None						ON	ON	

STRAHL

DIP SW A			1	2	3	4	5	6	7	8
COIN 1	1COIN	1PLAY	OFF	OFF	OFF					
	1COIN	2PLAY	ON	OFF	OFF					
	1COIN	3PLAY	OFF	ON	OFF					
	1COIN	4PLAY	ON	ON	OFF					
	2COIN	1PLAY	OFF	OFF	ON					
	3COIN	1PLAY	ON	OFF	ON					
	4COIN	1PLAY	OFF	ON	ON					
	5COIN	1PLAY	ON	ON	ON					
COIN 2	1COIN	1PLAY				OFF	OFF	OFF		
	1COIN	2PLAY				ON	OFF	OFF		
	1COIN	3PLAY				OFF	ON	OFF		
	1COIN	4PLAY				ON	ON	OFF		
	2COIN	1PLAY				OFF	OFF	ON		
	3COIN	1PLAY				ON	OFF	ON		
	4COIN	1PLAY				OFF	ON	ON		
5COIN	1PLAY				ON	ON	ON			
CONTINUE									OFF	
DEMO SOUND									ON	OFF
									ON	ON

DIP SW B

DIP SW B		1	2	3	4	5	6	7	8
NUMBERS	3	OFF	OFF						
	2	ON	OFF						
	4	OFF	ON						
	5	ON	ON						
.DIFFICULTY	NORMAL			OFF	OFF				
	EASY			ON	OFF				
	DIFFICULTY			OFF	ON				
	VERY DIFFICULTY			ON	ON				
BONUS	20,000 30,000						OFF	OFF	
	300,000 500,000						ON	ON	
							OFF	OFF	
							ON	ON	