

# TRIPLE FUN

SOLDER	PARTS
GND	1 GND
GND	2 GND
+5V	3 +5V
+5V	4 +5V
NC	5 NC
+12V	6 +12V
NC	7 NC
NC	8 NC
NC	9 NC
SPEAKER	10 SPEAKER
NC	11 NC
VIDEO G	12 VIDEO R
VIDEO SY	13 VIDEO B
NC	14 NC
NC	15 NC
COIN 2	16 COIN 1
2P START	17 1P START
2P UP	18 1P UP
2P DOWN	19 1P DOWN
2P LEFT	20 1P LEFT
2P RIGHT	21 1P RIGHT
2P SHOT	22 1P SHOT
NC	23 NC
NC	24 NC
NC	25 NC
NC	26 NC
GND	27 GND
GND	28 GND

DIP-SWITCH 1		1	2	3	4	5	6	7	8
COIN A	1COIN1PLAY	OFF	OFF	OFF					
	1COIN2PLAY	ON	OFF	OFF					
	1COIN3PLAY	OFF	ON	OFF					
	1COIN4PLAY	ON	ON	OFF					
	2COIN1PLAY	OFF	OFF	ON					
	3COIN1PLAY	ON	OFF	ON					
	4COIN1PLAY	OFF	ON	ON					
	5COIN1PLAY	ON	ON	ON					
	COIN B	1COIN1PLAY				OFF	OFF	OFF	
1COIN2PLAY					ON	OFF	OFF		
1COIN3PLAY					OFF	ON	OFF		
1COIN4PLAY					ON	ON	OFF		
2COIN1PLAY					OFF	OFF	ON		
3COIN1PLAY					ON	OFF	ON		
4COIN1PLAY					OFF	ON	ON		
5COIN1PLAY					ON	ON	ON		

DIP-SWITCH 2		1	2	3	4	5	6	7	8
TIME	2	OFF	OFF						
	1	ON	OFF						
	3	OFF	ON						
	4	ON	ON						
DEMO	YES			ON					
SOUND	NO			OFF					
MODE	GAME								OFF
	TEST								ON

## SUMMARY

THIS GAME HAS 5 STAGES. EACH STAGE CONSISTS OF MORE THAN 50 VARIETIES OF THREE DIFFERENT PARTS. THESE THREE DIFFERENT PARTS ARE :

1. HIDE AND SEEK : THE PICTURE SHOWS A PERSON IN THE SMALL BOX. THE PLAYER NEEDS TO FIND THE SAME PERSON IN THE BIG PICTURE WHICH CAN BE EXTENDED BY MOVING THE SCREEN.
2. MIX AND MATCH : THIS GAME SHOWS A PICTURE, THEN DISASSEMBLED TO PIECES. THE PLAYER NEEDS TO ASSEMBLE THE PIECES TO REPRODUCE THE PICTURE.
3. TAKE ANOTHER LOOK : THIS GAME SHOWS TWO PICTURES, THE CORRECT ONE ON THE LEFT AND THE WRONG ONE ON THE RIGHT. EACH PICTURE CONSISTS OF 49 SQUARE SEGMENTS. THE PLAYER NEEDS TO POINT OUT THE SEGMENTS WHICH ARE DIFFERENT.

## CONTROL PANEL

