

TWIN EAGLE

DIP SW 1

1	OFF	1	OFF	1	OFF	1	OFF	1	OFF
2	OFF	2	ON	2	ON	2	ON	2	ON
3	OFF	3	OFF	3	OFF	3	OFF	3	OFF
4	OFF	4	ON	4	ON	4	ON	4	ON
5	OFF	5	OFF	5	OFF	5	OFF	5	OFF
6	OFF	6	ON	6	ON	6	ON	6	ON
7	OFF	7	OFF	7	OFF	7	OFF	7	OFF
8	OFF	8	ON	8	ON	8	ON	8	ON

PARTS SIDE

1	GND
2	GND
3	+5V
4	+5V
5	+12V
6	POST
7	COIN COUNTER 1
8	COIN LOCKOUT 1
9	SPEAKER (+)
10	VIDEO RED
11	VIDEO BLUE
12	VIDEO GND
13	COIN 1
14	1P START
15	1P UP
16	1P DOWN
17	1P LEFT
18	1P RIGHT
19	1P SHOT BUTTON
20	1P BOMB BUTTON
21	GND
22	GND

SOLDER SIDE

1	GND
2	GND
3	+5V
4	+5V
5	+12V
6	POST
7	COIN COUNTER 2
8	COIN LOCKOUT 2
9	SPEAKER (-)
10	VIDEO GREEN
11	VIDEO SYNC
12	SERVICE SW
13	TILT SW
14	(COIN 2)
15	2P START
16	2P UP
17	2P DOWN
18	2P LEFT
19	2P RIGHT
20	2P SHOT BUTTON
21	2P BOMB BUTTON
22	GND
23	GND

DIP SW 2

1	OFF	1	OFF	1	OFF	1	OFF	1	OFF
2	ON	2	ON	2	ON	2	ON	2	ON
3	OFF	3	OFF	3	OFF	3	OFF	3	OFF
4	ON	4	ON	4	ON	4	ON	4	ON
5	OFF	5	OFF	5	OFF	5	OFF	5	OFF
6	OFF	6	ON	6	ON	6	ON	6	ON
7	OFF	7	OFF	7	OFF	7	OFF	7	OFF
8	OFF	8	ON	8	ON	8	ON	8	ON

DIFFICULTY

B	(Easy)
A	C
D	(Difficult)

BONUS CHARGE

3	No Bonus
5	500,000 only
1	1,000,000 only
2	500,000/1,500,000

COIN TYPE

Type 1	1
Type 2	2