


# USAAF MUSTANG

SOLDER SIDE	PIN #		PARTS SIDE
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
	E	5	
+12V	F	6	+12V
	H	7	
COIN COUNTER 2	J	8	COIN COUNTER 1
(GND)	K	9	(GND)
SPEAKER (-)	L	10	SPEAKER (+)
	M	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SWITCH	R	14	VIDEO GND
	S	15	
COIN SWITCH 2	T	16	COIN SWITCH 1
START SWITCH 2	U	17	START SWITCH 1
2 P CONTROL 1 UP	V	18	1 P CONTROL 1 UP
2 P CONTROL 2 DOWN	W	19	1 P CONTROL 2 DOWN
2 P CONTROL 3 LEFT	X	20	1 P CONTROL 3 LEFT
2 P CONTROL 4 RIGHT	Y	21	1 P CONTROL 4 RIGHT
2 P CONTROL 5 PUSH 1	Z	22	1 P CONTROL 5 PUSH 1
2 P CONTROL 6 PUSH 2	a	23	1 P CONTROL 6 PUSH 2
	b	24	
	c	25	
	d	26	
(GND)	e	27	GND
GND	f	28	GND




MONITOR  
HORIZONTAL

USAAF MUSTANG DIP SWITCH INSTRUCTION

DIP SWITCH 1

	1	2	3	4	5	6	7	8
NUMBER OF SHIP	X	X						
INITIAL 3 SHIPS	X	X						
INITIAL 2 SHIPS	O	X						
INITIAL 4 SHIPS	X	O						
INITIAL 5 SHIPS	O	O						
NORMAL		X	X					
DIFFICULT		O	X					
MORE DIFFICULT		X	O					
TOP DIFFICULT		O	O					
NO FLIP FLOP			X					
FLIP FLOP			O					

O ON  
X OFF



DIP SWITCH 2

	1	2	3	4	5	6	7	8
COIN SHUTE 1	X	X	X					
1 COIN 1 CREDIT	X	X	X					
1 COIN 2 CREDIT	O	X	X					
1 COIN 3 CREDIT	X	O	X					
1 COIN 4 CREDIT	O	O	X					
2 COIN 1 CREDIT	X	X	O					
3 COIN 1 CREDIT	O	X	O					
4 COIN 1 CREDIT	X	O	O					
FREE GAME	O	O	O					
COIN SHUTE 2			X	X	X			
1 COIN 1 CREDIT			X	X	X			
1 COIN 2 CREDIT			O	X	X			
1 COIN 3 CREDIT			X	O	X			
1 COIN 4 CREDIT			O	O	X			
2 COIN 1 CREDIT			X	X	O			
3 COIN 1 CREDIT			O	X	O			
4 COIN 1 CREDIT			X	O	O			
FREE GAME			O	O	O			
WITH SOUND						X		
NON SOUND						O		
DEMO								

