

秘密警察

UNDERCOVER COPS

56 PIN CONNECTOR

CONFORMING TO JAMMA STANDARD (3.96 mm pitch)

SOLDER SIDE		PARTS SIDE	
GND	A	1	GND
GND	B	2	GND
+5V	C	3	+5V
+5V	D	4	+5V
	E	5	
+12V	F	6	+12V
MISINSERTION PREVENTING KEY	H	7	MISINSERTION PREVENTING KEY
COIN COUNTER B	J	8	COIN COUNTER A
GND	K	9	GND
SPEAKER(-)	L	10	SPEAKER(+)
	M	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
	S	15	
COIN SW B	T	16	COIN SW A
2P START	U	17	1P START
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P SW A	Z	22	1P SW A
2P SW B	a	23	1P SW B
	b	24	
	c	25	
	d	26	
GND	e	27	GND
GND	f	28	GND

CN 5

1	GND
2	3P RIGHT
3	3P LEFT
4	3P DOWN
5	3P UP
6	3P START/COIN
7	
8	3P SW B
9	3P SW A

		SW 1							
		1	2	3	4	5	6	7	8
THE NUMBER OF WARRIERS GIVEN AT START	2	OFF	OFF						
	3	ON	OFF						
	4	OFF	ON						
	1	ON	ON						
DIFFICULTY	NORMAL			OFF	OFF				
	EASY			ON	OFF				
	HARD			OFF	ON				
				ON	ON				
ANYKEY *	YES						OFF		
	NO						ON		
SOUND IN ATTRACTIVE MODE	NO							OFF	
	YES							ON	
DIAGNOSTIC TEST	YES								OFF
	NO								ON

		SW 2							
		1	2	3	4	5	6	7	8
FLIP PICTURE	NO	OFF							
	YES	ON							
NUMBER OF SIMULTANEOUS PLAYERS	2		OFF						
	3		ON						
COIN SELECTOR*	COMMON		OFF						
	INDEPENDENT		ON						
MODE 1	1 COIN 1PLAY				OFF	OFF	OFF	OFF	OFF
	2 COINS 1PLAY				OFF	ON	OFF	OFF	OFF
	3 COINS 1PLAY				OFF	OFF	ON	OFF	OFF
	4 COINS 1PLAY				OFF	ON	ON	OFF	OFF
	5 COINS 1PLAY				OFF	OFF	OFF	ON	OFF
	6 COINS 1PLAY				OFF	ON	OFF	ON	OFF
	1 COIN 2PLAY				OFF	OFF	ON	ON	OFF
	1 COIN 3PLAY				OFF	ON	ON	ON	OFF
	1 COIN 4PLAY				OFF	OFF	OFF	OFF	ON
	1 COIN 5PLAY				OFF	ON	ON	OFF	ON
	1 COIN 6PLAY				OFF	OFF	ON	OFF	ON
	2 COINS 3PLAY				OFF	ON	ON	OFF	ON
	3 COINS 2PLAY				OFF	OFF	OFF	ON	ON
	4 COINS 3PLAY				OFF	ON	OFF	ON	ON
	CONTINUE COIN				OFF	OFF	ON	ON	ON
	FREE PLAY				OFF	ON	ON	ON	ON
MODE 2	A	1 COIN 1PLAY			ON	OFF	OFF		
		2 COINS 1PLAY			ON	ON	OFF		
		3 COINS 1PLAY			ON	OFF	ON		
		5 COINS 1PLAY			ON	ON	ON		
	B	1 COIN 2PLAY			ON			OFF	OFF
		1 COIN 3PLAY			ON			ON	OFF
		1 COIN 5PLAY			ON			OFF	ON
		1 COIN 6PLAY			ON			ON	ON

CONTINUE COIN is the mode which starts the game with 2 coins but continues it with 1 coin alone. When this mode is set, no other coin modes can be set. For two players, 4 coins to start, 2 coins to continue.