

# Video Ric

M A

B

GND	1	GND
GND	2	GND
+5 V	3	+5 V
+5 V	4	+5 V
+R V	5	+12 V
	6	
	7	
Lautsprecher (-)	8	Lautsprecher (+)
Service	9	
	10	Münze EIN
1 P START	11	2 P START
1 P AKT 1	12	
1 P " 2	13	
1 P LINKS	14	
1 P RECHTS	15	
1 P AUF	16	
1 P AB	17	
	18	
	19	
TV BLAU	20	TV-ROT
TV Synchr.	21	TV-GRÜN
	22	
	23	
	24	
	25	
	26	
	27	
	28	