


Whizz


INSTRUCTION MANUAL




- **HORIZONTAL CONVERSION GAME.**
- **1 OR 2 PLAYER CAN ENJOY WITH THIS GAME.**
- **SECOND PLAYER CAN JOIN GAME AT ANY TIME.**
- **8 THRILLING AND ACTIVE STAGES.**

● OVERVIEW


- CRT MONITOR : LANDSCAPESCREEN
- ARRANGING CONTROL PANNEL



LEVER




BUTTON 1



BUTTON 2

- BUTTON 1BOMB SHOOT BUTTON
- BUTTON 2GUN SHOOT BUTTON

● DIP SW POSITION



SOLDERING SIDE				COMPONENT SIDE
GND	A	1	GND	
GND	B	2	GND	
+5V	C	3	+5V	
+5V	D	4	+5V	
N.C.	E	5	N.C.	
+12V	F	6	+12V	
	H	7		
COIN COUNTER2	J	8	COIN COUNTER 1	
N. C.	K	9	N. C.	
SP (-)	L	10	SP (+)	
N.C.	M	11	N.C.	
VIDEO GREEN	N	12	VIDEO RED	
VIDEO SYNC	P	13	VIDEO BLUE	
SERVICE SW	R	14	VIDEO GND	
N.C.	S	15	N.C.	
COIN SW 2	T	16	COIN SW 1	
START SW 2	U	17	START SW 1	
2P CONTROL UP	V	18	1P CONTROL UP	
2P CONTROL DOWN	W	19	1P CONTROL DOWN	
2P CONTROL LEFT	X	20	1P CONTROL LEFT	
2P CONTROL RIGHT	Y	21	1P CONTROL RIGHT	
2P CONTROL PUSH1	Z	22	1P CONTROL PUSH1	
2P CONTROL PUSH2	a	23	1P CONTROL PUSH2	
N. C.	b	24	N. C.	
N. C.	c	25	N. C.	
N. C.	d	26	N. C.	
GND	e	27	GND	
GND	f	28	GND	

● CONNECTOR TYPE

CR7-56DA-3.96 : HIROSE
1168-056-009 : KEL

「WHIZZ」 DIP SWITCH INDEX

DIS sw A

	CONTENTS	1	2	3	4	5	6	7	8
MUSIC IN DEMO	YES —								<u>OFF</u>
	NO —								
CONTI- NUE MODE	YES —							<u>OFF</u>	
	NO —							ON	
BONUS PLAYER	100,000 ONLY					OFF	OFF		
	100,000 & EVERY 100,000					ON	<u>OFF</u>		
	150,000 & EVERY 150,000					OFF	ON		
	200,000 & EVERY 200,000					ON	ON		
PLAYER COUNT	3 —				<u>OFF</u>				
	5 —				ON				
DIFFI- CULT MODE	1 EASY	OFF	OFF	OFF					
	2	ON	OFF	OFF					
	3	OFF	ON	OFF					
	4 NORMAL	<u>ON</u>	<u>ON</u>	<u>OFF</u>					
	5	OFF	OFF	ON					
	6	ON	OFF	ON					
	7	OFF	ON	ON					
	8 DIFFICULT	ON	ON	ON					

DIP sw B

	CONTENTS	1	2	3	4	5	6	7	8
	NOT USED								<u>OFF</u> ON
	NOT USED							<u>OFF</u> ON	
1 COIN	1 COIN / 1 CREDIT				<u>OFF</u>	<u>OFF</u>	<u>OFF</u>		
	1 / 2				ON	OFF	OFF		
	1 / 3				OFF	ON	OFF		
	1 / 4				ON	ON	OFF		
	1 / 5				OFF	OFF	ON		
	2 / 1				ON	OFF	ON		
	3 / 1				OFF	ON	ON		
	4 / 1				ON	ON	ON		
2 COIN	1 COIN / 1 CREDIT	<u>OFF</u>	<u>OFF</u>	<u>OFF</u>					
	1 / 2	ON	OFF	OFF					
	1 / 3	OFF	ON	OFF					
	1 / 4	ON	ON	OFF					
	1 / 5	OFF	OFF	ON					
	2 / 1	ON	OFF	ON					
	3 / 1	OFF	ON	ON					
	4 / 1	ON	ON	ON					



PhilKo

PhilKo Corporation

ADD: 10, 3 GA-JONGRO, JONGRO-GU,
SEOUL, KOREA

TELEX: PHILKO K29617

FACSIMILE: (02) 274-2846

TEL: (02) 741-0101 / 744-1128