

WINNING ELEVEN

SOLDER SIDE	PIN #		PART SIDE
G N D	A	1	G N D
G N D	B	2	G N D
+ 5V	C	3	+ 5V
+ 5V	D	4	+ 5V
	E	5	
+ 12V	F	6	+ 12V
KEY	H	7	KEY
COIN COUNTER 2	J	8	COIN COUNTER 1
COIN COUNTERS 3	K	9	
SPEAKER (L)	L	10	SPEAKER (R)
AUDIO (GND)	M	11	
VIDEO GREEN	N	12	VIDEO RED
VIDEO SYNC	P	13	VIDEO BLUE
	R	14	VIDEO GND
COIN SW 3	S	15	TEST SW
COIN SW 2	T	16	COIN SW 1
START SW 2	U	17	START SW 1
2 P UP	V	18	1 P UP
2 P DOWN	W	19	1 P DOWN
2 P LEFT	X	20	1 P LEFT
2 P RIGHT	Y	21	1 P RIGHT
2 P PUSH 1	Z	22	1 P PUSH 1
2 P PUSH 2	a	23	1 P PUSH 2
2 P PUSH 3	b	24	1 P PUSH 3
2 P PUSH 4	c	25	1 P PUSH 4
	d	26	
G N D	e	27	G N D
G N D	f	28	G N D

DIP SWITCHES					
	2	1		COIN 1	
	4	3		COIN 2	
7	6	5		COIN 3	
8				DEMO SOUND	
ON	ON	ON	2 coin - 1 credit	COIN 1,2,3	
ON	ON	OFF	1 coin - 1 credit	COIN 1,2,3	
ON	OFF	ON	1 coin - 2 credits	COIN 1,2,3	
ON	OFF	OFF	1 coin - 3 credits	COIN 1,2,3	
OFF	ON	ON	1 coin - 4 credits	COIN 3	
OFF	ON	OFF	1 coin - 5 credits	COIN 3	
OFF	OFF	ON	1 coin - 6 credits	COIN 3	
OFF	OFF	OFF	1 coin - 7 credits	COIN 3	
ON			Demo sound		
OFF			No demo sound		

Game Adjust

Press Test and hold before Power on

