



# ZONAR™

## DIP SWITCH SETTINGS

DIP SWITCH I					DIP SWITCH II						
1	COIN SELECTOR 1				1	OFF	ON	ACCREDITED AIRCRAFT			
	1	OFF	ON	OFF		ON	3	5			
	2	2	OFF	OFF		ON	ON				
	Coin	1	1	1		2					
2	Credit	1	2	3	1	BONUS POINTS					
	3	OFF	ON	OFF	ON	2	OFF	ON	OFF	ON	
	4	4	OFF	OFF	ON	ON	3	OFF	OFF	ON	ON
	Coin	1	1	1	2	3	5000	10000	15000	20000	
3	Credit	1	2	3	1	PTS	PTS	PTS	PTS		
	COIN SELECTOR 2				4	OFF	ON				
	3	OFF	ON	OFF		ON					
	4	4	OFF	OFF		ON	ON				
Coin	1	1	1	2							
4	Credit	1	2	3	1	EASY	DIFFICULT				
	5	OFF	DON'T CHANGE		5	<i>LEICHT</i>	ON				
	6	OFF	DON'T CHANGE		6	OFF	DON'T CHANGE	PANEL B			
	7	OFF	ON	CONTROL	PANEL	7	OFF	DON'T CHANGE			
5	TABLE	UPRIGHT			8	OFF	DON'T CHANGE				
	8	OFF	ON	SCREEN							
6	TABLE	UPRIGHT									
	8	OFF	ON	SCREEN							