KINGDOM GRANDPRIX

DIP SW 1

		1	2	3	4	5	6	7	8
GAME STYLE	*COIN PLAY FREE PALY	OFF ON							
PICTURE INDICATE	*NORMAL REVERSE		OFF ON						
FUNCTION CHECK	*NORMAL PLAY TEST PATTERN			OFF ON					
DEMO SOUND	*ON NO SOUND				OFF ON				
*1COIN / 1CREDIT COIN SW1 1 2 2 1 2 3	*1COIN / 2CREDIT FOR 2 1 EUROPE 3 1 4 1					OFF ON OFF ON	OFF OFF ON ON		
*1COIN / 1CREDIT COIN SW1 1 2 2 1 2 3	*1COIN / 2CREDIT FOR 1 3 EUROPE 1 4 1 6							OFF ON OFF ON	OFF OFF ON ON

DIP SW 2

		1	2	3	4	5	6	7	8
DIFFICULTY	* B NORMAL A EASY C DIFFICULT D MORE DIFFICULT	OFF ON OFF ON	OFF OFF ON ON						
EXTER PLAYER	* 300,000 EACH 200,000/500,000 ONLY 200,000 ONLY NO EXTER PLAYER			OFF ON OFF ON	OFF OFF ON ON				
NUMBER OF PLAYER	* 3 5 2 1					OFF ON OFF ON	OFF OFF ON ON		
GAME MODE	* NORMAL MODE INVINCIBLE MODE							OFF ON	
CONTINUE PLAY	* ON OFF								OFF ON