V A P O R T R A I L

SOLDER SIDE		PARTS SIDE
GND	1	GND
GND	2	GND
+5V	3	+5V
+5V	4	+5V
	5	
+12V	6	+12V
	7	
COIN COUNTER 2	8	COIN COUNTER 1
(GND)	9	(GND)
SPEAKER(-)	10	SPEAKER(+)
AUDIO(GND)	11	AUDIO(+)
VIDEO GREEN	12	VIDEO RED
VIDEO SYNC	13	VIDEO BLUE
SERVICE SW	14	VIDEO GND
	15	
COIN SW 2	16	COIN SW 1
START SW 2	17	START SW 1
2P UP	18	1P UP
2P DOWN	19	1P DOWN
2P LEFT	20	1P LEFT
2P RIGHT	21	1P RIGHT
2P PUSH 1	22	1P PUSH 1
2P PUSH 2	23	1P PUSH 2
	24	
	25	
	26	
GND	27	GND
GND	28	GND

DIP SW 1	1	2	3	4	5	6	7	8
COIN 1	COIN 1			COIN 2				
1coin 1play	OFF	OFF	OFF	OFF	OFF	OFF		
1coin 1play	ON	OFF	OFF	ON	OFF	OFF		
1coin 3play	OFF	ON	OFF	OFF	ON	OFF		
1coin 4play	ON	ON	OFF	ON	ON	OFF		
1coin 5play	OFF	OFF	ON	OFF	OFF	ON		
1coin 6play	ON	OFF	ON	ON	OFF	ON		
2coin 1play	OFF	ON	ON	OFF	ON	ON		
3coin 1play	ON	ON	ON	ON	ON	ON		
SCREEN REVERSE							ON	
NORMAL							OFF	
DON'T CHANGE								OFF

DIP SW 2	1	2	3	4	5	6	7	8
NUMER OF LIVES								
3	OFF	OFF						
	ON	OFF						
5	OFF	ON						
2	ON	ON						
GAME DIFFICULTY								
NORMAL			OFF	OFF				
EASY			ON	OFF				
HARD			OFF	ON				
HARDEST			ON	ON				
EXTRA LIVES								
200k/600k P					OFF	OFF		
150k/300k/600k P					ON	OFF		
300k P					OFF	ON		
NONE					ON	ON		
CONTINUE MODE							OFF	
NOT CONTINUE							ON	
ATTRACT MODE SOUND								ON
NO ATTRACT MODE SOUND								OFF